


AMBILIGHT tv

Guía de inicio rápido


8100 Series




Herramienta necesaria para el ensamble





43"/50"/55"/65"




75"




43"(Q4xL16) : x4
50"/55"(Q4xL18) : x4
65"(M4xL20) : x4
75"(M5xL20) : x4




1 43"/50"/55"




65"/75"




2





3



A Instalación en el escritorio



B Instalación en la pared




43"

R


L

50"/55"/ 65"/75"



Distancia recomendada con la pared

10-20 cm




B

Diagonal (pulgadas/cm)	X (mm)	Y (mm)	Tamaño del tornillo	Largo del tornillo (mm)
43" / 108	200	100	M6	9-10
50" / 126	200	100	M6	9-10
55" / 139	200	100	M6	9-10
65" / 164	400	300	M8	12-22
75" / 189	400	300	M8	12-22

Distancia recomendada con la pared

7-10 cm



4

Conectate



www.philips.to/smartTV

La aplicación Philips Smart TV te permite cambiar de canal y ajustar el volumen, como si fuera un control remoto.


5

Registro y Soporte



www.philips.com/TVsupport

Regístrá tu televisor, obtené más información, descarga el manual de usuario y recibí asistencia




English

Read the safety instructions.

Español

Lea la información de seguridad.

43"/50"/55"



65"/75"

